

Legend

| | | | | | | | | | |
|--|--------------------------------------|--|------------------------------|--|---|--|----------------------------------|--|-------------------------------------|
| | Airbag | | Stored gas inflator | | Seat belt pretensioner | | SRS control unit | | Pedestrian protection active system |
| | Automatic rollover protection system | | Gas strut / Preloaded spring | | High strength zone | | Zone requiring special attention | | |
| | Battery low voltage | | Ultra capacitor, low voltage | | Fuel tank | | Gas tank | | Safety valve |
| | High voltage battery pack | | High voltage power cable | | High voltage device that disconnects high voltage | | Fuse box disabling high voltage | | High voltage ultra-capacitor |
| | Fuel tank content gasoline/ethanol | | Fuel tank content Diesel | | | | | | |



1. Identification / recognition




Lettering **KAMIQ** on the tailgate.




2. Immobilisation / stabilisation / lifting


2A - Immobilisation / stabilisation



Automatic gearbox
1. Shift selector lever into position "P".
2. Secure the vehicle with the parking brake.



Manual gearbox
1. Put the shift lever into neutral position.
2. Secure the vehicle with the parking brake.




Turn the ignition key to the "OFF position" and remove it

or





Press the START-STOP button.



Remove the key from the vehicle.

2B - Lifting

Lifting points




3. Disable direct hazards / safety regulations


3A - Shut power off



See chapter 2A





or



a) Locate the 12 V battery in the engine compartment, see chapter 3B.





b) Disconnect the 12V battery from the vehicle electrical system using a suitable tool.

1. Disconnect the negative pole (-).
2. Disconnect the positive pole (+).





3B - Access to 12V battery




4. Access to the occupants

High strength body areas



Glass types: 1. Laminated safety glass
2. Toughened safety glass



5. Stored energy / liquids / gases / solids

| | | |
|--|--|--------|
| | | 50L |
| | | 50L |
| | | 12V |
| | | 0,43Kg |

6. In case of fire



Use appropriate protective equipment!

7. In case of submersion

After recovering the vehicle from the water, drain the water.
Use appropriate protective equipment!



8. Towing / transportation / storage

Do not tow the vehicle on the front axles.



10. Explanation of pictograms used

| | | | | | | | | |
|----------------------------------|----------------------|--------------------------------------|-------------------------------|----------------------------|-----------------------------------|-----------------------------------|----------------------|--------------------------------|
| | | | | | | | | |
| Flammable | Environmental hazard | Corrosives | Hazardous to the human health | Explosive | Vehicle on fuel of liquid group 2 | Vehicle on fuel of liquid group 1 | General warning sign | Lifting point; central support |
| | | | | | | | | |
| Use water to extinguish the fire | Bonnet | Device to shut down power in vehicle | Remove smart key | Air-conditioning component | | | | |